

10' Floor Setup Instructions


10' - 2 X 4 CURVED

QTY STANDARD PARTS

- 1 pop-up frame
- 21 channel bars in fabric case
- 8 plastic peg caps
- 4 fabric panels 88½" H x 27"W
- 2 endcap panels 88½" H x 25½"W
- 2 halogen lights
- 2 light cords
- 1 spare halogen bulb

* verify all parts are present according to parts list before assembling.

* Keep graphics rolled when removing and inserting into case.



| | | | |
|--|---|---|---|
| <p>LIGHT CLIPS</p> <p>Remove frame from the case and place on table top with the light clips on top and facing towards you.</p> | <p>Insert plastic peg caps into slots on upper part of frame. Four on the front and two on the back.</p> | <p>LIGHT CLIPS</p> <p>Open the popup frame halfway by pulling up and out on the center of the frame.</p> | <p>Once the frame is open halfway, slide the halogen lights onto the light clips and insert the power cord into the back of the light.</p> |
| <p>LIGHTS</p> <p>Open the frame to its full open position. Once the frame is completely expanded, it will remain in the fully opened position.</p> | <p>Insert magnetic bars into frame. Start at the top, push the pointed end into the slot. Slide bottom of bar over metal peg to lock into place. Insert next bar into bottom of previous bar.</p> | <p>Continue inserting magnetic bars on front and then insert one column of bars on each back corner.</p> | <p>Attach fabric panels. Locate notches on top of panel and slide notch over peg cap. Unroll panel allowing it to attach magnetically to half of the magnetic bar as it unrolls. Repeat for all front panels.</p> |
| <p>ENDCAP</p> <p>To attach endcap panels, locate notches on top of panel and slide notch over peg cap. Unroll panel allowing it to attach to half the magnetic bar on the front and half of the magnetic bar on the back.</p> | <p>Display should appear as shown. Attach graphic panels by placing onto fabric panels in desired locations.</p> | <p>To store the unit, remove panels, endcaps, channel bars, peg caps and lights. Collapse frame. Stack panels and graphics with fabric and graphics side up. Roll up and insert into case. Insert frame and channel bars into case. Pack lights and peg caps into case cover. Close lid and secure all latches.</p> | |